



NWS-SPA1 Squeeze Personal Alarm

Congratulations on your decision to purchase this very cost-effective Squeeze Personal Alarm. This device can help protect you from unwanted advances or attack. Be sure to follow the instructions for maximum protection and remember that this device is a deterrent and users are encouraged to have alternative plans in place in addition to using this device.

Squeeze Personal Alarm Introduction

The Squeeze Personal Alarm is intended to help protect you from unwanted advances or attack. It is also used alert others to come to your aid should you fall over or require help for other reasons. The unit has a belt clip which can be attached to your belt, purse or almost anything and at the other end there is a ring which can be used to attach the alarm to your key chain. We recommend the use of a neck lanyard to minimise the alarm being inadvertently set off.

Important:

Before the unit will operate, there is a plastic tab which must first be removed from the back. Once removed, discard the plastic tab. The plastic tab was used to prevent the unit from activating in transit.

Battery Replacement:

This unit requires three (3) LR44 button cell batteries (included). When the light or alarm appears weak, the batteries will need to be replaced. Use a small screw driver to remove the four screws on the back of the unit and insert the new batteries following the polarity diagram.

Led Light Operation:

To turn on the LED light, press the circular button on the front of the unit. Release the button to turn off the light. This button doubles as the off button to turn the alarm off when activated.

Alarm Operation:

To activate the alarm, squeeze or press both sides of the unit at the same time. You do not have to continue to squeeze or press the sides; once activated, the alarm will continue to sound until turned off. To turn off the alarm press the circular button on the front of the unit.

This neat little device is just under 8cm (3 inches) long and easily fits in a handbag or pocket. The alarm is battery powered, 100% wireless and easy to use. Imagine the extra peace of mind this could bring to a student staying away from home. Great for when outdoors alone. Included is a mini LED torch for each location of keyholes etc. in the dark. Perfect for Students, Joggers, Delivery Workers, The Elderly (Easy activation).

A person is most likely to be attacked at night while walking to or from their car or home. This compact alarm easily attaches to your keys or clips to your purse or clothing so it's always within reach. The clip makes it ideal for Nurses and Care Staff to easily attach to a top pocket etc. Also because this alarm has no pull cords or straps it makes the unit more appealing to health care workers, the medical profession and care staff. Simply use an anti-bacterial wipe and the alarm is instantly clean.

Warranty:

Batteries are not covered by any warranty. Disconnect the battery if the alarm will not be in use for long periods of time. Whilst the product is made from tough ABS plastic, the manufacturer does not warrant the product against damage from being dropped or exposed to water (fluids). Like most things, occasionally there can be a failure which may have originated in the factory and we call this sort of failure as a Factory Defect. Generally, the defect presents right away or as soon as you test the unit. If for any reason you test your new Squeeze Personal Alarm and find it does not work, pack it up and post it back to our offices with a note on the issue along with a copy of your Invoice (purchase receipt) and we will replace it promptly, postage paid back to you. Retain your purchase receipt for any warranty claims. The warranty period is 90 days from the date of purchase. Return all claims, postage paid to your point of purchase.

Neighbourhood Watch Shop

Post Office Box 3065, Aberfoyle Park 5159 Telephone: (08) 8322-7705

Email: sales@neighbourhoodwatchshop.com.au

Neighbourhood Watch Shop Pty Ltd as the Trustee for NHWS Trust ABN 60 548 176 369

